



Husky

Recommended Installation, Maintenance
and Inspection Instructions

**Pressure Activated Ethanol Conventional
Nozzles**

XS® E10-E85

Nozzles

659504
659508

659559
659589

666104
^666154N

666164
1108459

1108659
^6595100N

6595179
6595181

11084181
11086179

SEE LISTING FOR DETAILS

IMPORTANT SAFETY INSTRUCTIONS - SAVE THESE INSTRUCTIONS IN A READILY ACCESSIBLE LOCATION.

⚠ WARNING Designed for use at motor fuel dispensing facilities only.

INSTALLATION INSTRUCTIONS

1. Turn off dispenser and relieve line pressure.
2. Apply Loctite® 567, Gasolia® Eseal, or other approved ethanol compatible sealant thinly to male threads of hose. Do not use Teflon® tape.
3. Only connect to E25/E85 compatible fittings.
4. Tighten approximately 1 to 2 turns past hand tight - do not overtighten.
5. Pressurize system and visually inspect for leaks.
6. Test nozzle for proper automatic shut off between 5 - 10 gpm / 18.9 - 37.9 Lpm.
7. Perform pressure activation test (no pressure / no flow test).

DO NOT OVERTIGHTEN. USE WRENCH ON HOSE NUT ONLY.

IF DRIVE OFF OCCURS

- Turn off dispenser and relieve line pressure.
- Visually check for fractured spout shear groove.
- Pressurize system and visually inspect for leaks.
- Check spout tip - should be in round and sensing port should be clear of debris.
- Perform flow test of nozzle auto shut off between 5 - 10 gpm / 18.9 - 37.9 Lpm.
- Perform pressure activation test (no pressure / no flow test).
- Check for electrical conductivity.

TESTING / MAINTENANCE / INSPECTION



Daily

- Check for leaks / stains.
- Check for loose spouts.
- Check for damage.
- Check for bent lever.
- Check for broken clip / trigger spring.



Monthly

- Check nozzle auto shut off between 5 - 10 gpm / 18.9 - 37.9 Lpm.
- Check "remove after" date.



Annually

- Check for electrical conductivity.
- Lubricate main valve stem.

- All drive aways, maintenance and inspection activities must be logged using the serial number of the individual product.
- Apply city, state, or federal testing regulations as appropriate.

**ANY TEST / INSPECTION FAILURE
REQUIRES IMMEDIATE EQUIPMENT
REPLACEMENT OR REMOVAL FROM
SERVICE.**

MADE IN THE USA

**ALWAYS ADHERE TO INSTALLATION / USAGE INSTRUCTIONS AND WARNINGS.**

Improper use may result in injury, damage, or hazardous spill.

**GENERAL WARNINGS / INSTRUCTIONS PERTAINING TO A RISK OF FIRE, ELECTRIC SHOCK OR INJURY TO PERSONS:**

- Use of equipment is at individuals' own risk.
- Always abide and adhere to city, state, and federal regulations regarding use and installation of dispensing equipment.
- Always follow the product manufacturer's installation & maintenance instructions.



- Always turn off all power to dispenser during maintenance and inspection activities.
- Always close the shear valves during maintenance and inspection activities.



- Always relieve pressure from system prior to performing maintenance activities.
- Always check continuity after installation using a megohmmeter (Refer to PEI RP 400 for details).



- Always replace or remove from service damaged or leaking dispensing equipment immediately.



- Always report leaks / spills / accidents to appropriate authorities.
- Always wear appropriate safety equipment during maintenance activities.



- Always have appropriate fire extinguishing equipment within 5 ft / 1.5 m of dispensers.
- Always use pipe sealant approved for E85 fueling.



- Always place containers on the ground before filling.



- Always discharge static electricity before using or servicing equipment by touching a metal part of the dispenser before and after fueling vehicle.



- Never smoke within 20 ft / 6.1 m of dispensers.



- Never keep in service past recommended life.



- Never leave the nozzle unattended while dispensing fuel.



- Never use sparking or flaming devices within 20 ft / 6.1 m of dispensers.



- Never use power tools near dispensers or to aid in the installation process.



- Never use cell phone within 20 ft / 6.1 m of dispensers.



- Never reenter car when fueling vehicle.
- Never allow gasoline to touch eyes or skin.



- Never use at flow rates in excess of regulatory guidelines.

- Never use at flow rates less than 5 gpm / 18.9 Lpm.

- Never dispense flammable material into unapproved containers.
- Never dispense fuel without a valid driver's license.

CAUTION: DO NOT TOP OFF!

Topping off can lead to spills and splashes.

IMPORTANT SAFETY INSTRUCTIONS - SAVE THESE INSTRUCTIONS IN A READILY ACCESSIBLE LOCATION.

WARRANTY

VAPOR PRODUCTS – Husky Corporation will, at its option, repair, replace, or credit the purchase price of any Husky® manufactured product which proves upon examination by Husky, to be defective in material and/or workmanship for a period of one (1) year of installation or fifteen (15) months from the manufacture date of shipment by Husky, whichever occurs first. The warranty period on repaired or replacement vapor recovery products is only for the remainder of the warranty period of the defective product.

CONVENTIONAL PRODUCTS – Husky Corporation will, at its option, repair, replace, or credit the purchase price of any Husky manufactured product which proves upon examination by Husky, to be defective in material and/or workmanship for a period of one (1) year from the manufacture date of shipment by Husky.

Buyer must return the products to Husky, transportation charges prepaid. This Warranty excludes the replaceable bellows, bellows spring assembly, spout assembly and scuff guard, unless (i) damage is obvious when the product is removed from shipping carton and (ii) the defective product is returned to Husky prior to use. This warranty does not apply to equipment or parts which have been installed improperly, damaged by misuse, improper operation or maintenance, or which are altered or repaired in any way.

The warranty provisions contained herein apply only to original purchasers who use the equipment for commercial or industrial purposes. There are no other warranties of merchantability, fitness for a particular purpose, or otherwise, and any other such warranties are hereby specifically disclaimed.

Husky assumes no liability for labor charges or other costs incurred by Buyer incidental to the service, adjustment, repair, return, removal or replacement of products. Husky assumes no liability for any incidental, consequential, or other damages under any warranty, express or implied, and all such liability is hereby expressly excluded.

Husky reserves the right to change or improve the design of any Husky fuel dispensing equipment without assuming any obligations to modify any fuel dispensing equipment previously manufactured.

OPERATION INSTRUCTIONS

- | | |
|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <ol style="list-style-type: none"> 1. Activate dispenser. 2. Insert spout into fill pipe opening. 3. Lower hose end of nozzle so the spout spring catches the inside of the fill pipe. 4. Raise the lever and begin fueling. 5. Nozzle will shut off automatically when the tank is full. | <ol style="list-style-type: none"> 6. Wait 15 seconds to allow any fuel remaining in the spout to drain. 7. Remove nozzle from fill pipe by raising hose end of the nozzle. 8. Return nozzle to nozzle boot. <p><small>NOTE: Nozzle is equipped with a unique Flo-Stop® device that shuts off the nozzle if it falls from fill pipe or raises above horizontal.</small></p> |
|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|

PRESSURE ACTIVATION TEST INSTRUCTIONS

- | | |
|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <ol style="list-style-type: none"> 1. Verify nozzle has hold open clip. 2. Verify dispenser is turn off. 3. Place nozzle spout into test can. 4. Pull up lever and latch clip - a small amount of fuel may flow until the line pressure is relieved. 5. Turn on dispenser and select grade - nozzle should not dispense fuel. 6. Release the lever. | <ol style="list-style-type: none"> 7. Pull up lever and latch clip - nozzle should dispense fuel. 8. Turn off dispenser - nozzle should stop dispensing fuel. 9. Turn dispenser on and select grade - nozzle should not dispense fuel. <p><small>NOTE: The no pressure / no flow device fulfills the NFPA Code 30A requirement regarding self-service nozzles with a hold open latch. If nozzle fails item #5 or #9, verify dispenser is not allowing constant pressure to the hose. If dispenser tests OK, replace nozzle.</small></p> |
|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|

SPOUT REPLACEMENT INSTRUCTIONS

- | | |
|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <p>Model 006207 Unlead E85 Spout Assembly</p> <ol style="list-style-type: none"> 1. Remove spout lock nut and spout. 2. Remove and discard spout seal. 3. Place new spout seal in groove. | <ol style="list-style-type: none"> 4. Insert new spout into body making sure the vent tube is in the port. 5. While holding the spout in proper alignment, tighten the spout lock nut firmly, approximately 35 - 60 lbf·ft / 47 - 81 N·m. Do not overtighten.. |
|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|

TROUBLESHOOTING GUIDE

Nozzle keeps shutting off or won't dispense...

1. Make sure dispenser is on and activated.
2. Slow down flow rate - use lower notch on clip.
3. Clean spout tip end.
4. Clean or replace filter.
5. Inspect Safe-T-Break®.
6. Replace spout assembly.
7. Check dispenser pressure - 19 psi / 1.3 bar to activate nozzle.
8. Remove nozzle and drain hose.

Nozzle won't shut off...

1. Check flow rate - minimum of 3 gpm / 11.4 Lpm required.
2. Remove nozzle and drain hose.

Nozzle leaks...

1. Check for loose spout.
2. Check hose connection.
3. Check for cracks in nozzle and hose threads.

Low flow rate...

1. Remove the flow limiter (if equipped) and check for debris.
2. Verify dispenser is not in slow flow rate mode.
3. Check for system leak.
4. Check dispenser filter for debris.

Flow rate above 10 gpm / 37.9 Lpm...

1. Verify flow limiter is being used - either inside or outside dispenser.
2. If equipped, check the flow limiter for debris.

GENERAL TECHNICAL DATA

Fuel Type	Test and warranty for all blends of Ethanol and Gasoline
Flow Rate	Unleaded w/o Flo-Equalizer® = 14 gpm / 52.9 Lpm
Body	Die cast aluminum
Disc	Fluorocarbon
Packing	Double O-ring seal protected by fiber reinforced Teflon®
Lever	One piece reinforced polymer
Shipping Weight	3.0 lbs / 1.3 kg
Threads	¾" / 19 mm NPT
Spout	13/16 in / 20.6 mm O.D.
Case Quantity	15
Listings	Default ^ NOT LISTED

FLO-EQUALIZER® INSTALLATION / REMOVAL INSTRUCTIONS

Model 007490 Standard Flo-Equalizer®

INSTALLATION

1. Turn off dispenser and relieve line pressure.
2. Disconnect nozzle from hose and drain.
3. Insert Flo-Equalizer®, small hole first, into the nozzle inlet.
4. Using the end of a deep well socket or similar tool, lightly tap the Flo-Equalizer® on the outer edge until snug.
5. Reconnect nozzle to hose following recommended installation instructions.

DISCLAIMER: In the event of pressure differential in excess of 25 psi / 1.7 bar across the Flo-Equalizer® or the presence of debris obstructing movement of internal components, the Flo-Equalizer® output may exceed 10 gpm / 37.9 Lpm.

NOTE: Field installation of the Flo-Equalizer® is NOT UL approved because improper installation may cause the nozzle to fail.

REMOVAL

1. Turn off dispenser and relieve line pressure.
2. Disconnect nozzle from hose and drain.
3. Using a scribe with a hooked tip or similar tool, insert the hooked tip end completely through the Flo-Equalizer® center.
4. Hook the edge of the Flo-Equalizer® and gently pull it out of the nozzle inlet.

HOLD OPEN CLIP INSTALLATION / REMOVAL INSTRUCTIONS

Model 003593 Hold Open Clip Kit

INSTALLATION

1. Remove nozzle from hose and drain.
2. Position latch spring under latch clip and hose them in place. The latch clip should straddle the mating holes in the trigger lever.
3. Insert latch rivet through latch clip and lever, making sure latch spring is secured in position by the rivet.
4. Install push nut on rivet - DO NOT hammer in place.
5. Squeeze lever several times to check operation.
6. Verify clip and lever are parallel.

NOTE: Field installation of the hold open clip is NOT UL approved because improper installation may cause the nozzle to fail.

REMOVAL

1. Remove nozzle from hose and drain.
2. Place nozzle on a flat surface in safe location.
3. Hold up on the latch clip to prevent rivet from rotating.
4. Drill off the riveted end using a ¼" / 6.4 mm bit.
5. Do not remove latch plate.

NOTE: Nozzles can be ordered without clips.

GUARD REPLACEMENT INSTRUCTIONS

NOZZLE GUARD

Model 004145

1. Remove nozzle from hose.
2. Remove old guard.
3. Install new guard over spout and pull back to cover nozzle body.
4. Re-install nozzle to hose.

NOZZLE REGUARD

Model 001806

1. Cut old guard at nozzle inlet and remove from nozzle.
2. Install new guard over spout and pull back to cover nozzle body.
3. Pull tie through the eyelets and loop under nozzle inlet.
4. Pull tightly and trim off excess tie.

PROTECTION PACKAGE

Model 001506

1. Remove nozzle from hose.
2. Remove old guard.
3. Install new guard over spout and pull back to cover nozzle body.
4. Install waffle splash guard over spout lock nut.
5. Re-install nozzle to hose.

REGUARD PACKAGE

Model 001809

1. Cut old guard at nozzle inlet and remove from nozzle.
2. Install new guard over spout and pull back to cover nozzle body.
3. Pull tie through the eyelets and loop under nozzle inlet.
4. Pull tightly and trim off excess tie.
5. Install waffle splash guard over spout lock nut.

POPD® GUARD

Model 006665

1. Remove nozzle from hose.
2. Remove old guard.
3. Install new POPD® guard over spout and pull back to cover nozzle body.
4. Reinstall nozzle to hose.
5. Test nozzle for automatic shut-off.
6. Install desired advertisement and clear cover (model 006628).

WAFFLE SPLASH GUARD

Model 001808

1. Remove old waffle splash guard.
2. Install new waffle splash guard over spout lock nut.

POPD® REGUARD

Model 007205

1. Remove waffle splash guard (if applicable).
2. Cut old nozzle guard at nozzle inlet and remove from nozzle.
3. Install new POPD® guard over spout and pull back to cover nozzle body.
4. Pull tie through the eyelets and loop under nozzle inlet.
5. Pull tightly and trim off excess tie.
6. Re-install waffle splash guard (if applicable) over spout lock nut.
7. Install desired advertisement and clear cover (model 006628).

POPD® CLEAR COVER

Model 006628

1. Trim advertisement to 3.75 in / 95.25 mm x 3.75 in / 99.25 mm.
2. Notch corners of advertisement approximately .375 in / 9.5 mm x .375 in / 9.5 mm.
3. Turn clear cover "inside out".
4. Center advertisement on POPD® guard, using the notched corners as guides, and fold over edges.
5. Lay clear cover over advertisement, making sure the advertisement stays centered, and turn it "right side out".
6. Confirm the cover is securely in place.

E25/E85 & Warning logo are standard on all nozzle guards

ACCESSORIES

Model 000397

Unleaded spout gauge