

**BJE**MODEL #7635, 7636, 10872, 11177, & 11178
Recommended Installation, Maintenance
and Inspection Instructions**LEAK
GUARD****Leak Guard**

IMPORTANT SAFETY INSTRUCTIONS - SAVE THESE INSTRUCTIONS IN A READILY ACCESSIBLE LOCATION.

**WARNING** Never use with gasoline or highly flammable liquids.**INSTALLATION INSTRUCTIONS**

NOTE: *Always adhere to installation / usage instructions and warnings. Improper use may result in injury, damage or hazardous spill.*

1. Determine tank depth in inches.
2. Remove eyelet connector from end of chain and save.
3. Holding chain taut, measure tank depth (determined in step 1) from base of weighted float.
4. Subtract 2" (50.8 mm) from determined measurement and mark chain.
5. Cut chain on mark and feed chain through bottom of shaft and back out of either hole on the sides of shaft.
6. Secure chain with eyelet by crimping eyelet closed.
7. Apply appropriate thread sealant to male threads of overfill guard.
8. Slowly lower weighted float into tank and tighten gauge, approximately 1 to 2 turns past hand tight. Do not overtighten.
9. Confirm orange indicator is at proper level - if tank is empty it should not be visible. (If visible, remove sight glass and depress orange indicator. Reinstall sight glass. If still visible, recheck measurements in steps 2 - 4 and shorten chain as required.)

**DO NOT OVERTIGHTEN. DO NOT USE SIGHT GLASS AS A WRENCH.
ALWAYS USE CHAIN TO LOWER FLOAT TO BOTTOM OF TANK.**

TESTING / MAINTENANCE / INSPECTION

Daily

- Confirm orange indicator is not visible.
- Confirm sight glass is not damaged.



Quarterly

- Remove gauge from tank and inspect chain for damage.

- Apply city, state, or federal testing regulations as appropriate.

**ANY TEST / INSPECTION
FAILURE REQUIRES IMMEDIATE
EQUIPMENT REPLACEMENT OR
REMOVAL FROM SERVICE.**

MADE IN THE USA

**ALWAYS ADHERE TO INSTALLATION / USAGE INSTRUCTIONS AND WARNINGS.**

Improper use may result in injury, damage, or hazardous spill.

**GENERAL WARNINGS / INSTRUCTIONS PERTAINING TO A RISK OF FIRE, ELECTRIC SHOCK OR INJURY TO PERSONS:**

- Use of equipment is at individuals' own risk.
- Always abide and adhere to city, state, and federal regulations regarding use and installation of monitoring equipment.
- Always follow the product manufacturer's installation and maintenance instructions.
- Always turn off all power to monitor during maintenance activities.



- Always replace or remove from service damaged equipment immediately.
- Always report leaks / spills / accidents to appropriate authorities.



- Always wear appropriate safety equipment during maintenance and inspection activities.



- Always have appropriate fire extinguishing equipment within 5 ft / 1.5 m of tanks.



- Always use Teflon tape or appropriate thread sealant.



- The tank contents are the sole responsibility of the tank owner.



- Never allow waste product to touch eyes or skin.



- Never install monitors outdoors without proper protection from the elements.



- Never use on below ground storage tanks.



- Never exceed the maximum milliamps specified in manufacturer's installation and maintenance instructions.



- Never solely rely on this product; there is no substitute for human supervision.

- Never to be used as a component of any automatically controlled pump transfer system.



Proposition

65

WARNING: The Materials Used As Colored Decorations On The Exterior Of This Product Contain Lead And/OR Cadmium, Chemicals Known To The State Of California To Cause Birth Defects Or Other Reproductive Harm.

IMPORTANT SAFETY INSTRUCTIONS - SAVE THESE INSTRUCTIONS IN A READILY ACCESSIBLE LOCATION.

WARRANTY

Husky Corporation will, at its option, repair, replace, or credit the purchase price of any BJE® now part of Husky®, product deemed to be defective in material and/or workmanship for a period of one (1) year.

Buyer must return the products to Husky, transportation charges prepaid. The warranty excludes damages due to malfunction, failure to follow manufacturer's installation, operation or maintenance instructions and guidelines, unauthorized modifications or alterations, abuse, or misuse.

The warranty provisions contained herein apply only to original purchasers who use the equipment for commercial or industrial purposes. There are not other warranties of merchantability, fitness for a particular purpose, or otherwise, and any other such warranties are hereby specifically disclaimed.

Husky assumes no liability for labor charges or other costs incurred by Buyer incidental to the service, adjustment, repair, return, removal or replacement of products. Husky is not responsible for any losses (including loss of profits or revenues) incurred by the purchaser during the time necessary to repair the equipment. Husky assumes no liability for any incidental, consequential, or other damages under any warranty, express or implied, and all such liability is hereby expressly excluded.

Husky reserves the right to change or improve the design of any Husky Oil Filter Crushers, Tank Monitors, Tank Gauges, Overfill Alarms, Overfill Accessories, Air Shut-off Valves, Solenoid Valves, and Electronic Drain Valves without assuming any obligations to modify any Husky Oil Filter Crushers, Tank Monitors, Tank Gauges, Overfill Alarms, Overfill Accessories, Air Shut-off Valves, Solenoid Valves, and Electronic Drain Valves previously manufactured.