

**BJE**Recommended Installation, Maintenance
and Inspection Instructions**Overfill
Guard****Overfill Guard**

007640

007741

008670

008719

007641

007742

008672

011179

007740

007743

008674

011180

IMPORTANT SAFETY INSTRUCTIONS - SAVE THESE INSTRUCTIONS IN A READILY ACCESSIBLE LOCATION.

**WARNING** Never use with gasoline or highly flammable liquids.**INSTALLATION INSTRUCTIONS***NOTE: Always adhere to installation / usage instructions and warnings. Improper use may result in injury, damage or hazardous spill.*

1. Determine desired liquid level for which orange indicator will appear.
2. Remove eyelet connector from end of chain and save.
3. Holding chain taut, measure the desired liquid level (determined in step 1) from the base of the weighted float.
4. Subtract 2" (50.8 mm) from determined measurement and mark chain.
5. Cut chain on mark and feed chain through bottom of shaft and back out of either hole on the sides of shaft.
6. Secure chain with eyelet by crimping eyelet closed.
7. Apply appropriate thread sealant to male threads of overfill guard.
8. Slowly lower weighted float into tank and tighten gauge, approximately 1 to 2 turns past hand tight. Do not overtighten.
9. Confirm orange indicator is not visible. (If visible, remove sight glass and depress orange indicator. Reinstall sight glass. If still visible, recheck measurement in step 1 and shorten chain as required.)

DO NOT OVERTIGHTEN. DO NOT USE SIGHT GLASS AS A WRENCH.**ALWAYS USE CHAIN TO LOWER FLOAT TO BOTTOM OF TANK.****TESTING / MAINTENANCE / INSPECTION**

Daily

- Confirm orange indicator is not visible.
- Confirm sight glass is not damaged.



Quarterly

- Remove gauge from tank and inspect chain for damage.

- Apply city, state, or federal testing regulations as appropriate.

**ANY TEST / INSPECTION
FAILURE REQUIRES IMMEDIATE
EQUIPMENT REPLACEMENT OR
REMOVAL FROM SERVICE.**

MADE IN THE USA

**ALWAYS ADHERE TO INSTALLATION / USAGE INSTRUCTIONS AND WARNINGS.**

Improper use may result in injury, damage, or hazardous spill.

**GENERAL WARNINGS / INSTRUCTIONS PERTAINING TO A RISK OF FIRE, ELECTRIC SHOCK OR INJURY TO PERSONS:**

- Use of equipment is at individuals' own risk.
- Always abide and adhere to city, state, and federal regulations regarding use and installation of monitoring equipment.



- Always follow the product manufacturer's installation and maintenance instructions.
- Always turn off all power to monitor during maintenance activities.
- Always replace or remove from service damaged equipment immediately.



- Always report leaks / spills / accidents to appropriate authorities.



- Always wear appropriate safety equipment during maintenance and inspection activities.



- Always have appropriate fire extinguishing equipment within 5 ft / 1.5 m of tanks.

- Always use appropriate thread sealant.



- The tank contents are the sole responsibility of the tank owner.



- Never allow waste product to touch eyes or skin.



- Never install monitors outdoors without proper protection from the elements.



- Never use on below ground storage tanks.
- Never exceed the maximum milliamps specified in manufacturer's installation and maintenance instructions.



- Never solely rely on this product; there is no substitute for human supervision.

- Never to be used as a component of any automatically controlled pump transfer system.



Proposition

65

WARNING: The Materials Used As Colored Decorations On The Exterior Of This Product Contain Lead And/Or Cadmium, Chemicals Known To The State Of California To Cause Birth Defects Or Other Reproductive Harm.

IMPORTANT SAFETY INSTRUCTIONS - SAVE THESE INSTRUCTIONS IN A READILY ACCESSIBLE LOCATION.

WARRANTY

Husky Corporation will, at its option, repair, replace, or credit the purchase price of any BJE® product deemed to be defective in material and/or workmanship for a period of one (1) year.

Buyer must return the products to Husky®, transportation charges prepaid. The warranty excludes damages due to malfunction, failure to follow manufacturer's installation, operation or maintenance instructions and guidelines, unauthorized modifications or alterations, abuse, or misuse.

The warranty provisions contained herein apply only to original purchasers who use the equipment for commercial or industrial purposes. There are not other warranties of merchantability, fitness for a particular purpose, or otherwise, and any other such warranties are hereby specifically disclaimed.

Husky assumes no liability for labor charges or other costs incurred by Buyer incidental to the service, adjustment, repair, return, removal or replacement of products. Husky is not responsible for any losses (including loss of profits or revenues) incurred by the purchaser during the time necessary to repair the equipment. Husky assumes no liability for any incidental, consequential, or other damages under any warranty, express or implied, and all such liability is hereby expressly excluded.

Husky reserves the right to change or improve the design of any Husky Oil Filter Crushers, Tank Monitors, Tank Gauges, Overfill Alarms, Overfill Accessories, Air Shut-off Valves, Solenoid Valves, and Electronic Drain Valves without assuming any obligations to modify any Husky Oil Filter Crushers, Tank Monitors, Tank Gauges, Overfill Alarms, Overfill Accessories, Air Shut-off Valves, Solenoid Valves, and Electronic Drain Valves previously manufactured.